



Your responsibility for the perfect coffee experience

The perfect coffee experience depends on a perfectly cleaned coffee machine. Increase the quality of your products!

Clean your coffee machine at least once a day and more frequently if necessary.

Follow the 5-step method for all removable parts.



Fill the pitcher with cold water and 50 ml of cleaning solution.



Place the pitcher under Autosteam and soak Autosteam for approx. 1 minute.



Press the product button for steam.
Autosteam is cleaned.



Empty the pitcher and fill it with cold water.



Place the pitcher under Autosteam.



Press the product button for steam.
Autosteam is rinsed.



Empty the pitcher and wipe Autosteam with a cloth.