

Cleaning Instructions

for Vitality Counter Top Juice Dispensers Model #JDF4

Daily sanitizing:

- 1.** Open front door and remove the 4 concentrate containers. Pour existing product into clean containers for temporary storage during cleaning process and clean containers thoroughly.
- 2.** Prepare a wash solution that is one ounce of liquid detergent for every gallon of warm water.
- 3.** Using a soft cloth, wash interior of refrigeration area; dispense shelf, etc. until all traces of juice concentrate are eliminated. Wash down all exterior surfaces of the dispenser as well as the surrounding counter top.
- 4.** Prepare a sanitizing solution using a chlorine sanitizer, following the sanitizer manufacturers recommended proportion of agent to warm water to insure at least 200 ppm available chlorine in the solution.
- 5.** Pour approximately 32 ozs of sanitizing solution into each of the 4 concentrate containers.
- 6.** Place the 4 containers with sanitizing solution into the dispenser and close the front door.
- 7.** Dispense each station until dispensed product is clear (no traces of juice in dispense).
- 8.** Leave sanitizer in system for 5 minutes.
- 9.** While sanitizer is in the dispenser, remove dispense nozzles (4 juice and 1 water) and soak for 2 minutes in a container of sanitizing solution.
- 10.** Rinse dispense nozzles in clean water, inspect for damaged or missing o-rings and place back on dispenser.
- 11.** Remove containers, dispose of remaining sanitizer and clean tanks with warm water.
- 12.** Refill concentrate tanks with clean water and refit into the dispenser.
- 13.** Dispense each station until clear (no traces of sanitizer in dispense).
- 14.** Remove containers, dispose of remaining water, refill containers with juice concentrate and put containers back in dispenser.
- 15.** Dispense until you see juice coming from the nozzle. The juice dispenser is now sanitized.
- 16.** To prevent concentrate build up, repeat this procedure daily.
- 17.** This will take approximately 12 minutes per dispenser.

